

- ORDER OF ASSEMBLY:
1. FASTEN ENDS TO ROOF & FLOOR.
 2. $\frac{1}{8} \times \frac{3}{16}$ POSTS
 3. SIDE SLATS
 4. OUTSIDE POSTS "Z" IRONS

