

## BOLSTER ADAPTER AND TRUCK MOUNTING INSTRUCTIONS

This kit is designed specifically to adapt ALL NATION #3845 or #3848 trucks or any truck with NMRA standard height bolster to ATLAS cars.

Remove sub-floor from car body by prying up at four bosses with a thin blade knife. Do this carefully so as not to break the bosses. Remove trucks from sub-floor. Note that one body bolster has side bearings cast on. These must be trimmed down to clear the side bearings on the trucks. Insert bushings into king pin holes from the top. Line up carefully and press in until top of bushing is flush with top of floor. Place coil spring over threads of bolster screw and fasten truck to floor.