SECTION "AA"

SECTION OF SALOON WINDOW

SECTION "BB"

SECTION "CC"

SECTION "DD"

NOTE- WHEN APPLYING NEW FLOORS, USE STANDARD FREIGHT CAR LUMBER (SCRIBE) EACH SIDE OF CAR, UNDER CENTERS ONLY. FOR THE BALANCE OF CAR, USE MAPLE FLOORING

CLASS	USED ON SERIES
NE 7	13960-13999
NE 7	13925-13949
NE 8	13905-13924
NE 6	13880-13904
NE 8	13855-13879
NE 8	13830-13854
NE 9	13805-13829
NE 9	13765-13789
NE 9	13730-13804

REFERENCE PLAN
BRAKE RIGGING
CUPOLA DRAWING
DRAFT GEAR
TRUCK
SIDE FRAME
BOLSTER
COUPLER
UNDERFRAME